

KICKIT™


BILLET ALUMINUM KICKSTANDS

Thank you for your purchase! We are confident that you will be pleased with the quality of our product.

Instructions: 2012-14 KTM EXC/XCW/XCFW (PMB-01-3008)

NOTE: We recommend using a thread-locking agent on all bolt threads.

- 1) Remove the bolt attaching the stock kickstand. Slide the kickstand off the frame. Detach and remove the kickstand spring.
- 2) Remove the two Kickstand Stop Bolts located above and below the stock kickstand (see the picture below). If the bolts are difficult to remove, use a heat gun to help break up the thread locking agent.
- 3) Slide the kickstand onto the frame and secure with the two 10x20 button head bolts. The two bolts provided replace the bolts removed in step two.
- 4) Periodically check all mounting bolts for tightness.



Maintenance:

Clean and lubricate the kickstand pivot area after each ride! We recommend using a heavy-duty chain lube, or WD-40. If necessary, you can remove the back cover plate for additional cleaning. Never remove the kickstand leg from the pivot pin! Do not use this kickstand as an aid when kick-starting your bike, it will cause premature damage.

Parts List:

- 1-Kickstand**
- 2-10x20 BH**

Check out our Spark Arrestor Endcaps, Billet Cargo Racks, Shark Fins and other billet accessories at...

